

# Bearing-sitter

Tool Kit includes 3D printed ABS and Nylon inserting tools:

- Handle-insert tool for 6803 (ID17mm - OD26mm)
- Adaptor for 6801 (ID12mm - OD21mm)
- Adaptor for 6802 (ID15mm - OD24mm)
- Adaptor for 6903 (ID17mm - OD30mm)

## COMPATIBLE WITH:

HyperFront HyperBoost/3 F Hyper JF	6803 bearings 17-26mm
HyperRear (1&2) HyperBoost/3 R Hyper JR HyperCamber (1&2)	6802 bearings 15-24mm 6803 bearings 17-26mm
CyberFront SL CyberFront SP CyberFront SPD-1	6801 bearings 12-21mm
CyberFront SPD-2/3+	6802 bearings 15-24mm
CyberRear SL-(1&2) CyberRear SP(2) CyberRear SPD-(2&3+)	6802 bearings 15-24mm 6803 bearings 17-26mm

## BEARING INSTALLATION:

Before replacing a bearing learn well these basic info:

[www.extralite.com](http://www.extralite.com)--> Tips and manuals --> Bearings

Each tool is designed for a specific bearing size and to apply pressure only onto its outer race. Use only a plastic mallet to apply pressure onto the Handle-tool.

Oil hubshell bore before installing the new bearing.

Warning: pressure or hits on the bearing's internal race will permanently damage balls and races of your new bearing.

