

OctaOne

FEATURES

Standard: BCD 104mm 4 bolts.

Compatibility: single chainring setups.

Standard SRAM XD Drive 11s chains and also other 9-10-11s chains.

Material: 7075 T6, "hart coating" finishing.

INSTALLATION

- 1) Position OctaOne directly on the internal side of the crank spider (do not use spacers).
- 2) Insert the 4 billet fittings into spider holes.
- 3) Apply grease or mild threadlock (243 Loctite or equivalent) under bolt head and on bolt thread.
- 4) Tighten at 5-6 Nm 4 standard chainring male bolts.

WARNING

Male chainring bolts must reach internal face of chainring.

Do not use shorter bolts.

EXTRALITE