

Bearing-sitter 2

Tool Kit includes 3D printed Nylon inserting tools:

- Handle-insert tool for 6803 (ID17mm - OD26mm)
- Adaptor for 6801 (ID12mm - OD21mm)
- Adaptor for 6802 (ID15mm - OD24mm)
- Adaptor for 6903 (ID17mm - OD30mm)

COMPATIBLE WITH:

HyperFront HyperBoost/3 F HyperSmart3 F Hyper JF	6803 bearings 17-26mm
HyperRear (1&2) HyperBoost/3 R HyperSmart3 R Hyper JR HyperCamber (1&2)	6802 bearings 15-24mm 6803 bearings 17-26mm
CyberFront SL - SL-B CyberFront SP / SP-B CyberFront SPD/C 2/3+	6801 bearings 12-21mm
CyberFront SPD/C-2/3+	6802 bearings 15-24mm
CyberRear SL (1&2) CyberRear SP/SP-2+/SP 2B+ CyberRear SPD/C 2/3+	6802 bearings 15-24mm 6803 bearings 17-26mm

BEARING INSTALLATION:

Before replacing a bearing learn well these basic info:

www.extralite.com--> Tech Tips --> Bearing Installation

Each tool is designed for a specific bearing size, applying pressure only to its outer race. Only use a plastic mallet to apply pressure to the handle tool. Oil the hub shell bore before installing the new bearing.

Warning: applying pressure or hits to the inner race of the bearing will permanently damage the balls and races of your new bearing.

